



# RAPIDSHINE

## Application and Specifications

### Application

- Before application, wash your vehicle thoroughly to avoid any dust, wax, oil, grease and other contamination. Then you don't have to dry the surfaces. Just let the water drain for 5-6 seconds. You can remove excess water with a cloth in areas where water does not drain, such as the vehicle roof.
- Shake the product before use. Spray on one square meter around 10-15 times and gently buff in circular motion with dry, lint- free Nasiol Microfiber Cloth until there is no moisture or mist on the surface.
- After two hours of drying, the product will start to show its effect.
- Please wait 24 hours to cure and become resistant to abrasion and chemicals, before any detergent-based washing.

### Specifications

Packaging	500 mL
Appearance	Milky liquid
Durability	up to 6 months
Dry Film Thickness	700-800 nm
Consumption per Unit Area	8-10 mL/m <sup>2</sup>
Density @23°C	0,99
pH Value	7-7,5
Dry to Touch Time	2h
Application Temperature	5°C-45°C (≤50%RH)
Water Contact Angle	102.7°
Water Sliding Angle	18°