



# CABINCARE

## Application and Specifications

### Application

- Surfaces should be dry and free of any dust, stain, and other contamination. Application should be made in a shaded and well-ventilated area. The product is sprayed approximately 80-100 mL for a 1m<sup>2</sup>. Spray with a standard Nasiol CabinCare bottle till the surface becomes slightly wet. Surfaces which do not absorb product should be spread with a cloth slightly. Wait for 24 hours for drying and curing period.
- Product effectiveness may change according to fabric type. Make a spot test on hidden part of your fabric.
- Keep the coated surface away from direct sunlight, dust, water and other contamination during the curing period. Ventilate the space/interior well for following hours of the application.

### Specifications

Packaging	500 mL
Durability	Up to 6 Months
Chemical Resistance	11>pH>1
Dry Film Thickness	75-100 nm
Consumption per Unit Area	80-100 ml/m <sup>2</sup>
Density @23°C	0.809 g/cm <sup>3</sup>
pH Value	1.4-1.6
Breathability (EN 1062-1)	Category 1
Application Temperature	5°C-30°C (≤50% RH)
Temperature Durability	110°C
Water Repellency (ISO-4920)	100/100
Water Contact Angle	144° @10 μL
Water Contact Angle After “2000 Wet Scrub (ISO-11998:2006)	126° @10 μL
Water Sliding Angle	7° @20 μL
Oil Contact Angle	92° @10 μL
Dry-to-Touch Time	6h
REACH Compliance	Yes